


APD.CIRC.PF

CIRCULAR PANEL WITH 25mm PICTURE FRAME





SPECIFICATION

DESCRIPTION	Circular Panel - 25mm Picture Frame
FIRE RATING	Non Fire Rated - Manufactured from non combustible materials in accordance with BS476 Part 4
COMPOSITION	Flush Metal Door Face 1.0 mm Thick Zintec Steel Polyester Powder Coated in 20% Ral9010 White Semi-gloss
LOCKING	To unlock, exert upward pressure on the door face whilst turning anti-clockwise. Once the door has being disengaged from the frame pins then the door can be lowered. The safety chain will have to be removed to allow full removal of the door. To lock is a reverse of above proceedure.
FITTING	Screw fix through the frame into a suitable trimming.

LOCKING OPTIONS









KEY LOCK TAMPER-PROOF

WATERPROOF QUARTER TURN KEY LOCK

SLOTTED CAM LOCI









THREE-WAY LOCKING

TOUCH CATCH

HEAVY DUTY

BUDGET LOCK

X

CATCH

DIMENSIONS

Please ensure that on installation of the access panel, the actual size of structural opening in the wall/ceiling needs to be 5mm larger than the overall panel size e.g. structural opening for 600 diameter will be 605 diameter (See sizes below).

Sizes	Structural Opening
300 diameter	305 diameter
450 diameter	455 diameter
600 diameter	605 diameter

Bespoke sizes are also available

FITTING INSTRUCTIONS

Note: the access panel may require extra support and bracing to allow safe operation.

- Insert frame into structural opening which needs to be 5mm larger than panel size, ensuring frame is flush with surface. Then screw fix through fixing points. Additional packers may be needed to prevent distortion of the frame. DO NOT fix through the face of frame.
- Simple to operate: remove the plastic plug, insert the Key into the budget lock and rotate 90 degrees. Ensure there is sufficient clearance for the lock to operate correctly.
- Access Panels with a beaded frame are designed for a wet finish. Scrim tape must be applied to all beaded edges prior to plastering. IMPORTANT NOTE: If scrim tape is not used the plaster may not adhere to the access panel's frame.

Refit the door and check operation. Ensure there is sufficient clearance behind the frame for the budget lock to operate correctly.